



US Patent Pending

Superior Tailgate Installation Instructions

Remove tailgate

First, you will want to remove the current tailgate by unplugging the wiring harness and disconnect safety cables from the tailgate. You are ready to remove your current tailgate at this time.

**Some customers may chose to leave their factory camera in their factory tailgate and purchase a new wiring harness and camera from their dealership for new tailgate. Superior Tailgates are fitted for factory wiring harness and camera. After market fittings could vary.

If you're transferring the current camera and wiring harness, remove them.

Component List



- A. Camera Face Plate (1)
- B. Face Plate Camera Insert (1 set bolted in camera face plate)
- C. 8-32 Socket Head Cap Screws (SHCS) & Washers (2)
- D. 8-32 Socket Head Cap Screws (SHCS) (8)
- E. Latch Pin Bushings (2 replacements)
- F. Driver's Side Hinge Bushing (1, already installed; can be removed if unnecessary)

Installation Steps

1. Install the camera in the face plate by removing the insert. (Make sure to insert the factory camera correctly.)
2. Run the camera wiring harness up through the bottom of the tailgate, using the pocket and exiting at the camera housing.
3. Connect the wiring harness to the camera.
4. Secure the camera face plate to the housing with the 8 included bolts. (Apply grease to the threads to prevent corrosion.)
5. Replace the latch pin bushings with the new ones included.



6. Remove the bolt out of the safety strap eyelet that goes on the tailgate.



7. You are ready to install the tailgate.
8. Hold the tailgate in place and insert the bolt, plastic spacer, and washer into the latch, tightening until snug. Repeat on both sides.



9. Run the wiring harness back through the truck bed slot and reconnect it.
10. Carefully close the tailgate and adjust the latch pins to fit properly.

***If you have questions please reach Superior Tailgates at 1-620-222-2023
info@superiortailgatesusa.com***